


N°	CHANNEL LIST	
	STANDARD mode 14 channels	SHARPY mode 16 channels
1	COLOUR WHEEL	COLOUR WHEEL
2	STOPPER / STROBE	STOPPER / STROBE
3	DIMMER	DIMMER
4	DIMMER FINE	STATIC GOBO CHANGE
5	STATIC GOBO CHANGE	PRISM INSERTION
6	PRISM INSERTION	PRISM ROTATION
7	PRISM ROTATION	DIMMER FINE
8	FOCUS	-
9	PAN	FOCUS
10	PAN FINE	PAN
11	TILT	PAN FINE
12	TILT FINE	TILT
13	RESET	TILT FINE
14	FUNCTION	FUNCTION
15	-	RESET
16	-	-

STANDARD mode	SHARPY mode	DMX Value	Function																																																														
1	1		<p><b>COLOUR WHEEL</b></p> <table border="1"> <tr><td>0 - 4</td><td>Empty position</td></tr> <tr><td>5 - 8</td><td>Empty + Dark red</td></tr> <tr><td>9 - 12</td><td>Dark red</td></tr> <tr><td>13 - 16</td><td>Dark red + Orange</td></tr> <tr><td>17 - 21</td><td>Orange</td></tr> <tr><td>22 - 25</td><td>Orange + Aquamarine</td></tr> <tr><td>26 - 29</td><td>Aquamarine</td></tr> <tr><td>30 - 33</td><td>Aquamarine + Deep green</td></tr> <tr><td>34 - 38</td><td>Deep green</td></tr> <tr><td>39 - 42</td><td>Deep green + Light green</td></tr> <tr><td>43 - 46</td><td>Light green</td></tr> <tr><td>47 - 50</td><td>Light green + Lavender</td></tr> <tr><td>51 - 55</td><td>Lavender</td></tr> <tr><td>56 - 59</td><td>Lavender + Pink</td></tr> <tr><td>60 - 63</td><td>Pink</td></tr> <tr><td>64 - 67</td><td>Pink + Yellow</td></tr> <tr><td>68 - 71</td><td>Yellow</td></tr> <tr><td>72 - 76</td><td>Yellow + Magenta</td></tr> <tr><td>77 - 80</td><td>Magenta</td></tr> <tr><td>81 - 84</td><td>Magenta + Cyan</td></tr> <tr><td>85 - 88</td><td>Cyan</td></tr> <tr><td>89 - 93</td><td>Cyan + CTO2</td></tr> <tr><td>94 - 97</td><td>CTO2</td></tr> <tr><td>98 - 101</td><td>CTO2+ CTO1</td></tr> <tr><td>102 - 105</td><td>CTO1</td></tr> <tr><td>106 - 110</td><td>CTO1+ CTB</td></tr> <tr><td>111 - 114</td><td>CTB</td></tr> <tr><td>115 - 118</td><td>CTB + Dark blue</td></tr> <tr><td>119 - 122</td><td>Dark blue</td></tr> <tr><td>123 - 127</td><td>Dark blue + Empty pos</td></tr> <tr><td>128 - 255</td><td>Continuous colour wheel CCW rotation at linearly variable speed from slow to fast</td></tr> </table>	0 - 4	Empty position	5 - 8	Empty + Dark red	9 - 12	Dark red	13 - 16	Dark red + Orange	17 - 21	Orange	22 - 25	Orange + Aquamarine	26 - 29	Aquamarine	30 - 33	Aquamarine + Deep green	34 - 38	Deep green	39 - 42	Deep green + Light green	43 - 46	Light green	47 - 50	Light green + Lavender	51 - 55	Lavender	56 - 59	Lavender + Pink	60 - 63	Pink	64 - 67	Pink + Yellow	68 - 71	Yellow	72 - 76	Yellow + Magenta	77 - 80	Magenta	81 - 84	Magenta + Cyan	85 - 88	Cyan	89 - 93	Cyan + CTO2	94 - 97	CTO2	98 - 101	CTO2+ CTO1	102 - 105	CTO1	106 - 110	CTO1+ CTB	111 - 114	CTB	115 - 118	CTB + Dark blue	119 - 122	Dark blue	123 - 127	Dark blue + Empty pos	128 - 255	Continuous colour wheel CCW rotation at linearly variable speed from slow to fast
0 - 4	Empty position																																																																
5 - 8	Empty + Dark red																																																																
9 - 12	Dark red																																																																
13 - 16	Dark red + Orange																																																																
17 - 21	Orange																																																																
22 - 25	Orange + Aquamarine																																																																
26 - 29	Aquamarine																																																																
30 - 33	Aquamarine + Deep green																																																																
34 - 38	Deep green																																																																
39 - 42	Deep green + Light green																																																																
43 - 46	Light green																																																																
47 - 50	Light green + Lavender																																																																
51 - 55	Lavender																																																																
56 - 59	Lavender + Pink																																																																
60 - 63	Pink																																																																
64 - 67	Pink + Yellow																																																																
68 - 71	Yellow																																																																
72 - 76	Yellow + Magenta																																																																
77 - 80	Magenta																																																																
81 - 84	Magenta + Cyan																																																																
85 - 88	Cyan																																																																
89 - 93	Cyan + CTO2																																																																
94 - 97	CTO2																																																																
98 - 101	CTO2+ CTO1																																																																
102 - 105	CTO1																																																																
106 - 110	CTO1+ CTB																																																																
111 - 114	CTB																																																																
115 - 118	CTB + Dark blue																																																																
119 - 122	Dark blue																																																																
123 - 127	Dark blue + Empty pos																																																																
128 - 255	Continuous colour wheel CCW rotation at linearly variable speed from slow to fast																																																																

<b>STANDARD mode</b>	<b>SHARPY mode</b>	<b>DMX Value</b>	<b>Function</b>
<b>2</b>	<b>2</b>		<b>STOPPER / STROBE</b>
		0 - 3	Light OFF
		4 - 103	Strobe at linearly variable frequency from low (1 flash/sec) to high (25 flashes/sec)
		104 - 107	Light ON
		108 - 207	Pulsation at linearly variable speed from slow to fast
		208 - 212	Light ON
		213 - 225	Random Strobe at low frequency
		226 - 238	Random Strobe at medium frequency
		239 - 251	Random Strobe at high frequency
		252 - 255	Light ON
<b>3</b>	<b>3</b>		<b>DIMMER</b>
		0 - 255	Light output linearly increase from no-light to maximum brightness.
<b>4</b>	<b>7</b>		<b>DIMMER FINE</b>
		0 - 255	Fine Dimmer brightness

STANDARD mode	SHARPY mode	DMX Value	Function
			<b>STATIC GOBO CHANGE</b>
			
		0 - 3	Empty position
		4 - 7	Gobo 1
		8 - 11	Gobo 2
		12 - 15	Gobo 3
		16 - 19	Gobo 4
		20 - 23	Gobo 5
		24 - 27	Gobo 6
		28 - 31	Gobo 7
		32 - 35	Gobo 8
		36 - 39	Gobo 9
		40 - 43	Gobo 10
		44 - 47	Gobo 11
		48 - 51	Gobo 12
		52 - 55	Gobo 13
		56 - 59	Gobo 14
		60 - 63	Gobo 15
		64 - 67	Gobo 16
		68 - 71	Gobo 17
		72 - 113	Continuous gobo wheel CCW rotation at linearly variable speed from fast to slow
		114 - 117	Stop rotation
		118 - 159	Continuous gobo wheel CW rotation at linearly variable speed from slow to fast
		160 - 165	Gobo 1 shakes at variable speed from slow to fast
		166 - 171	Gobo 2 shakes ...
		172 - 176	Gobo 3 shakes ...
		177 - 182	Gobo 4 shakes ...
		183 - 187	Gobo 5 shakes ...
		188 - 193	Gobo 6 shakes ...
		194 - 199	Gobo 7 shakes ...
		200 - 204	Gobo 8 shakes ...
		205 - 210	Gobo 9 shakes ...
		211 - 215	Gobo 10 shakes ...
		216 - 221	Gobo 11 shakes ...
		222 - 227	Gobo 12 shakes ...
		228 - 232	Gobo 13 shakes ...
		233 - 238	Gobo 14 shakes ...
		239 - 243	Gobo 15 shakes ...
		244 - 249	Gobo 16 shakes ...
		250 - 255	Gobo 17 shakes ...

5

4

4

STANDARD mode	SHARPY mode	DMX Value	Function
<b>6</b>	<b>5</b>		<b>PRISM INSERTION</b>
		0 - 127	Prism out
		128 - 255	Prism 8-facet into the light beam
<b>7</b>	<b>6</b>		<b>PRISM ROTATION</b>
		0 - 21	Prism indexing: 0° to 90° range
		21 - 42	Prism indexing: 90° to 180° range
		42 - 63	Prism indexing: 180° to 270° range
		63 - 84	Prism indexing: 270° to 360° range
		84 - 105	Prism indexing: 360° to 450° range
		105 - 127	Prism indexing: 450° to 540° range
		128 - 190	Continuous CW prism rotation at linearly variable speed from fast to slow
		191 - 192	Stop rotation
<b>8</b>	<b>9</b>		<b>FOCUS</b>
		0 - 255	Focus moves linearly from far to near position
<b>9</b>	<b>10</b>		<b>PAN</b>
		0 - 255	Pan movement/positioning from 0° to 540°
<b>10</b>	<b>11</b>		<b>PAN FINE</b>
		0 - 255	Fine Pan positioning
<b>11</b>	<b>12</b>		<b>TILT</b>
		0 - 255	Tilt movement/positioning from 0° to 244°
<b>12</b>	<b>13</b>		<b>TILT FINE</b>
		0 - 255	Fine Tilt positioning
<b>13</b>	<b>15</b>		<b>RESET</b>
		0 - 25	Unused range
		26 - 76	Effects Reset Effects Reset sequence is activated passing through the unused levels range and staying in this range for 5 seconds
		77 - 127	Pan / Tilt Reset Pan/Tilt Reset sequence passing through the unused levels range and staying in this range for 5 seconds.
		128 - 255	Complete Reset All-effects Reset sequence passing through the unused levels range and staying in this range for 5 seconds.

STANDARD mode	SHARPY mode	DMX Value	Function
			<b>FUNCTION</b>
		0 – 10	Unused range
		11 – 20	Led frequency 600 Hz
		21 – 30	Led frequency 1200 Hz (default)
		31 – 40	Led frequency 2000 Hz
		41 – 50	Led frequency 4000 Hz
		51 – 60	Led frequency 8000 Hz
		61 – 70	Led frequency 16 KHz
		71 – 80	Led frequency 25 KHz
		81 – 90	Fan Mode Auto (default)
		91 – 100	Fan Mode SLN
		101 – 110	Fan Mode Constant
		111 – 120	Pan/Tilt slow speed
		121 – 130	Pan/Tilt medium speed
		131 – 140	Pan/Tilt fast speed (default)
		141 - 255	Free
			The functions are activated/selected passing through the unused levels range and staying in the necessary range for 5 seconds.

### IMPORTANT

To prevent accidental breakage of the effects, which could collide with each others during transport, before switching the projector OFF, check that all the fixture Channels have been excluded (DMX level = 0 bit.).